

Certificate of Analysis

For Research Use Only Not for Human or Animal Consumption

KPL SureBlue[™] TMB Microwell Peroxidase Substrate (1-Component)

PART CODE: LOT NUMBER: SIZE 5120-0077 (52-00-03) 10709695 DESCRIPTION: This liquid substrate system develops a dark blue soluble product when reacted with horseradish peroxidase labeled conjugates in microwell plates or tubes. It is not recommended for membrane or immunohistochemical staining assays. FORM/STORAGE: Liquid. Store refrigerated at 2 - 8°C. CONTENT: The one component system is supplied as 1000 mL bottles, from bulk Lot No. 10709695. The KPL SureBlue ^{IIII} TMB Microwell Peroxidase Substrate (1-Component) contains 3,3',5.5' tetramethyl-benzidine in an acidic bulfer. The concentration of the Hydrogen Peroxide is 0.01%. STABILITY: Product is stable for three years from date of manufacture when stored property. DATE OF MANUFACTURE: 20 JUN 2024 RECOMMENDED REDISPENSING KPL SureBlue ^{IIII} TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: • Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. • Never pipete direcity from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue ^{IIII} TM B to the primary container. • Avoid deposure to Silica-based maternals including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may doestabilize the dye complex and result in the development of background color. • Redispense into a		
peroxidase labeled conjugates in microwell plates or tubes. It is not recommended for membrane or immunohistochemical staining assays. FORM/STORAGE: Liquid. Store refrigerated at 2 - 8°C. CONTENT: The one component system is supplied as 1000 mL bottles, from bulk Lot No. 10709695. The KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) contains 3,3,5,5' tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide is 0.01%. STABILITY: Product is stable for three years from date of manufacture when stored properly. DATE OF MANUFACTURE: 20 JUN 2024 RECOMMENDED REDISPENSING KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: • Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. • Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. • Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not return excess this may compromise substrate performance. • HDPE and LDPE bottles should be utilized as they are received directly from the munufacturer, washing of bottles is not recommended. • HDPE and LDPE bottles should be utilized as they are received directly from the munufacturer, washing of bottles is not recommended.	LOT NUMBER:	10709695
 CONTENT: The one component system is supplied as 1000 mL bottles, from bulk Lot No. 10709695. The KPL SureBlue[™] TMB Microwell Peroxidase Substrate (1-Component) contains 3.3'5.5' tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide is 0.01%. STABILITY: Product is stable for three years from date of manufacture when stored properly. DATE OF MANUFACTURE: 20 JUN 2024 RECOMMENDED KPL SureBlue[™] TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. Never pipete directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue[™] TMB to the primary container. Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. Redispense substrate using Cole-Parmer C-Flex tubing and on ot reuse tubing. Avoid redispensing with all other tubings including slicone, latex, and Tygon. Gravity fill or the use of a peristaltic pump is advised. Avoid substrate contact with any metallic surfaces. For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167. 	DESCRIPTION:	peroxidase labeled conjugates in microwell plates or tubes. It is not recommended for membrane
KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) contains 3,3',5,5'- tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide is 0.01%. STABILITY: Product is stable for three years from date of manufacture when stored properly. DATE OF MANUFACTURE: 20 JUN 2024 RECOMMENDED REDISPENSING KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. Avoid exposure to silica-based materials incluing borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refliter as this may destabilize the dye complex and result in the development of background color. Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. Redispense substrate contact with any metallic surfaces. Avoid substrate contact with any metallic surfaces. Avoid substrate contact with any metallic surfaces. For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167. 	FORM/STORAGE:	Liquid. Store refrigerated at 2 - 8°C.
DATE OF MANUFACTURE: 20 JUN 2024 RECOMMENDED REDISPENSING KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: • • Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. • Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. • Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. • Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. • HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. • Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. • Gravity fill or the use of a peristaltic pump is advised. • Avoid substrate contact with any metallic surfaces. • For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167.	CONTENT:	KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) contains 3,3',5,5'- tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide
MANUFACTURE: 20 JUN 2024 RECOMMENDED REDISPENSING KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: • Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. • Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. • Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. • Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. • HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. • Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. • Gravity fill or the use of a peristaltic pump is advised. • Avoid substrate contact with any metallic surfaces. • For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167.	STABILITY:	Product is stable for three years from date of manufacture when stored properly.
 REDISPENSING to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlueTM TMB to the primary container. Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. Gravity fill or the use of a peristaltic pump is advised. Avoid substrate contact with any metallic surfaces. For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167. 		20 JUN 2024
10 JUL 2024	REDISPENSING	 to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. Gravity fill or the use of a peristaltic pump is advised. Avoid substrate contact with any metallic surfaces. For further details concerning the redispensing of this product, please contact the Technical
QA Verified By Date	$\mathcal{D}_{\mathcal{C}}$	10 JUL 2024
	QA Verified By	Date

www.seracare.com